Motorola RAZR^2 V9m Programming Steps

STEP	ACTION
1	Enter the following into the phone without stopping - #+0+7+3+8+8+7+*. • Phone will prompt user to the Security Code.
2	Enter 2+3+6+1+9+7 and press “OK”. • You are now in Programming Menu.
3	Scroll down to “User Activation” and press “Select” using left soft key. • Phone will prompt user to enter the Subsidy Password.
4	Enter the OTSL or MSL code and press “OK”.
5	With the “MIN” selected, press the center navigation key.
6	Use the “CLR” key to delete existing digits.
7	Enter the 10 digit MSID and press “OK” With the “MDN” selected, press the center navigation key.
8	Use the “CLR” key to delete existing digits.
9	Enter the 10 digit MDN and press “OK”.
10	Press “Done” and then press “Exit”. • Phone will reset and is now programmed.